User Manual

Allen-Bradley

Bulletin 1608P ProDySC Dynamic Voltage Sag Corrector

1608P— 200 Amp Models

Allen-Bradley • Rockwell Software

Rockwell Automation

Important User Information

Solid-state equipment has operational characteristics differing from those of electromechanical equipment. Safety Guidelines for the Application, Installation and Maintenance of Solid State Controls (publication SGI-1.1 available from your local Rockwell Automation sales office or online at http://www.rockwellautomation.com/literature/) describes some important differences between solid-state equipment and hard-wired electromechanical devices. Because of this difference, and also because of the wide variety of uses for solid-state equipment, all persons responsible for applying this equipment must satisfy themselves that each intended application of this equipment is acceptable.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited.

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.

	WARNING: Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.
	ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequence.
	SHOCK HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.
	BURN HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.
IMPORTANT	Identifies information that is critical for successful application and understanding of the product.

ProDySC, Allen-Bradley, Rockwell Software, Rockwell Automation, and TechConnect are trademarks of Rockwell Automation, Inc. Trademarks not belonging to Rockwell Automation are property of their respective companies.

Additional Resources

These documents contain additional information concerning related products from Rockwell Automation.

Resource	Description
Industrial Automation Wiring and Grounding Guidelines, publication 1770-4.1	Provides general guidelines for installing a Rockwell Automation industrial system.
Product Certifications website, http://www.ab.com	Provides declarations of conformity, certificates, and other certification details.

You can view or download publications at http:/www.rockwellautomation.com/literature/. To order paper copies of technical documentation, contact your local Allen-Bradley distributor or Rockwell Automation sales representative.

Important User Information 2
Additional Resources 2

Ch 1 - Introduction
Safety Considerations 5

Ch 2 - Installation
Installation Check List 7
Inspecting and Unpacking 7
Location (Environment) 7
Floor Mounting 8
Clearance 8
Bypass Switch 8
Circuit Breaker Recommendations 8
Electrical Terminations 9
Accessing Terminations 9
3-Wire vs. 4-Wire Configurations 10
3- Wire Models 10
4- Wire Models 11
Electrical Terminations and Ratings 12

Ch 3 - Communications
Dry Contacts 13
Serial Communications Port 14

Ch 4 - Applying Power

Ch 5 - Display Screen
Overview 17
Home Screen 19
System Status 19
Voltage Sag Events 20
Voltage Sag Log 20
Voltage Sag Detail 21
Voltage Sag RMS Voltage Charts 22
Voltage Sag Notification 22
System Events 23
System Event Log 23
System Event Detail 24
System Event Notification 25
System Configuration 26
Model Information 26
Run System Tests 27
Diagnostics Mode 27

Ch 6 - Maintenance
Preventative Maintenance 29
Monthly Checks 29
3-6 Month Checks 29
Fuse Replacement 31
Fuse Rating Charts 32
Transient Voltage Surge Suppressor (TVSS) 32
Circuit Breaker CBI, Safety Interlocks and Stored Energy 32

Ch 7 - Specifications and Dimensions
Technical Specifications 33
Approximate Dimensions 34

Notes:

Introduction

The Allen-Bradley Bulletin 1608P ProDySC Dynamic Sag Corrector is engineered to provide years of trouble-free voltage sag (dip) protection. The patented DySC technology does not use batteries, requires only routine maintenance, includes three-stage transient voltage surge suppression, and has unparalleled energy efficiency. Most electronic devices found in industry today are susceptible to power disturbances. A momentary sag in line voltage can reset or damage sensitive production equipment. The ProDySC provides instantaneous dynamic sag correction to help your equipment ride through these common events. The ProDySC connects normal utility power directly to the load until a voltage sag occurs. During a sag, the ProDySC inverter is activated-adding missing voltage to keep the load voltage within the normal range. When utility power returns to normal, the inverter is deactivated and the ProDySC is quickly ready to correct the next sag.

The ProDySC reports these voltage sag events through its integrated touch screen display and provides system status, voltage sag notification and history, runtime statistics and system history in a simple and intuitive touch-based user interface.

Safety Considerations

The ProDySC is designed to operate in industrial applications. Follow these guidelines to ensure that the safety and installation of the ProDySC are handled with appropriate care.

SHOCK HAZARD: The ProDySC has high voltage remaining up to 5 minutes after disconnection from the AC line. Touching exposed or disconnected terminals, cables or parts of the ProDySC can lead to serious injuries or even death. Wait for a minimum of 5 minutes before performing any service or testing on the ProDySC after power is removed. High voltage remains if red LED indicators above capacitor banks are lighted. Keep the cabinet doors closed and locked to ensure proper cooling airflow and to protect personnel from dangerous voltages inside the ProDySC.

ATTENTION: - To reduce the risk of fire or electric shock, install this ProDySC in a temperature and humidity controlled, indoor environment, free of conductive contaminants.

- Avoid installing the ProDySC directly near heat-emitting equipment such as ovens, heaters, or furnaces.
- Ambient temperature must not exceed 40°C (104°F).
- Do not operate near water or excessive humidity (95% max).
- When punching or drilling holes for conduit fittings, take care to avoid dropping metallic particles inside the enclosure as this can result in electrical damage.
- The system is not intended for outdoor use.
- The operating environment should be maintained within the parameters stated in this manual.
- Only authorized service personnel should perform service on the ProDySC.
- Ensure all power is disconnected before performing installation or service.

ATTENTION: Internal components can be easily damaged by electrostatic discharge (ESD). Do not touch circuit boards or electronic components with hands or metal objects. The ProDySC is not rated to directly power life support equipment.

- Ensure the area around the ProDySC is clean and uncluttered.
- Observe all DANGER, CAUTION, and WARNING notices affixed to the inside and outside of the equipment.

Installation

Installation Check List

Before proceeding, please take a few minutes to review the necessary steps to install your ProDySC.

- All packing materials and restraints have been removed.
- The ProDySC is placed in its installed location.
- All conduits and cables are properly routed to the ProDySC.
- All power cables are properly terminated.
- A ground conductor is properly installed and terminated.
- If neutral connection is required that it is properly terminated on the ProDySC.
- The area around the installed ProDySC is clean and dust-free.
- Adequate work space exists around the ProDySC.
- Adequate lighting is provided around the ProDySC.
- Operational checks have been reviewed and completed.

Inspecting and Unpacking

- Lift only at the base with a fork truck or pallet jack
- Carefully inspect the outer packaging for evidence of damage during transit. Do not install a damaged cabinet. Report any damage to the carrier and contact your local sales or service immediately.
- Check the ProDySC label for correct model number with the packaging list to ensure you have received the correct voltage, current, and wiring configurations.
- After removing the packaging material, inspect the contents for any evidence of physical damage, and compare each item with the Bill of Lading. If damage has occurred or shortages are evident contact your carrier immediately.

Location (Environment)

The ProDySC must be installed in a protected environment. The location must provide adequate airflow around the ProDySC in an atmosphere free from excessive dust, corrosive fumes, or conductive contaminants. Do not operate the ProDySC in an environment where the ambient temperature or humidity is beyond the specified limits given in this manual.

Floor Mounting

The ProDySC is to be secured to the floor using fasteners and fittings appropriate for the type of floor. Holes are provided in the base channels; see Figure 1 for mounting dimensions.

Note: Top or bottom cable entry is allowed. See Figure 1 and Figure 2 on page 9.

Figure 1 - Bottom View Floor Mount Dimensions



Clearance

ProDySC doors hinge on both right and left. See Figure 26 on page 34 for dimensions including door swing. Leave required clearances:

- Door swing must allow doors to open at least 90 degrees
- 12” [300mm] clearance on left side and rear for cooling airflow
- 4”[100mm] on right side for air filter clearance when right door opens

Bypass Switch

Installation of an external maintenance bypass switch is recommended for service and/or maintenance. Typical switch arrangements are shown in Figure 3 on page 10 and Figure 4 on page 11. Contact Rockwell Automation for recommendations and requirements.

Circuit Breaker Recommendations

Branch circuit protection upstream of the ProDySC is required. Recommended circuit breakers and maximum allowed circuit breaker ratings are listed in Table 1. Branch circuit protection rated less than the ProDySC current rating may result in nuisance tripping.

Table 1 - Recommended Branch Circuit Protection

ProDySC Rating	Max. MCCB Rating
200 A	250 A

Electrical Terminations

The ProDySC must be installed by a qualified electrician, in compliance with all local and national electric codes. The ProDySC input (line) and output (load) terminals are located behind the right door. Terminal details are shown in Figure 5 on page 12.

Accessing Terminations

For top entry remove the top gland plate, shown in Figure 2, to access input and output terminals. This plate may be removed for drilling or punching holes for conduit. Alternate bottom entry should utilize the bottom gland plate shown in Figure 1. Access to the communications port is above the front doors, as shown in Figure 6 on page 13. A separate conduit knock-out is provided for top entry of communications conductors, as shown in Figure 2.

Note: When punching or drilling holes for conduit fittings, take care to avoid dropping metallic particles inside the enclosure. Metallic contamination will void the product warranty.

Figure 2 - Top Conductor Entry



WARNING: Metallic particles inside the enclosure will void the warranty.

3-Wire vs. 4-Wire Configurations

ProDySC models are available for use with either 3-wire (L1, L2, L3) or 4-wire (L1, L2, L3, N) sources. The input N conductor must be connected to 4-wire models for proper operation. Do not connect a N conductor to 3-wire models.

3- Wire Models

Bulletin 1608P part numbers containing V3 are configured for 3-wire source (L1, L2, L3) and 3-wire loads (X1, X2, X3). Do not connect a N conductor to 3-wire models. Figure 3 shows the 3-wire ProDySC system wiring schematically, including the recommended Bypass Switch.

Figure 3 - ProDySC 3-Wire Configuration



Note: The 3-wire ProDySC models rated greater than 240V have not been evaluated by Underwriter's Laboratories, Inc.(R) for connection to a corner-grounded or ungrounded delta power source. Contact Rockwell Automation Technical Support for assistance.

4- Wire Models

Bulletin 1608P part numbers containing V4 are configured for 4-wire source (L1, L2, L3, N) and either 3-wire or 4-wire loads. The source N conductor must be connected for proper operation of these models. Connect both input and output N conductors to the bus bar labeled NEUTRAL (See Figure 5). Figure 4 shows the 4-wire ProDySC system wiring schematically, including the recommended Bypass Switch.

Figure 4 - ProDySC 4-Wire Configuration.



Electrical Terminations and Ratings

Input terminal blocks are marked L1, L2, and L3 for the source connections. Output terminal blocks are marked X1, X2, and X3 for the load connections (See Figure 5). In 4-wire models only, connect both input and output N conductors to the NEUTRAL bus bar. Do not connect to the NEUTRAL bus bar in 3-wire models. The door must be closed and latched securely when the wiring is completed.

Figure 5 - Electrical Terminations



- Input/Output mechanical lugs conductor range: AWG 6 to 350 kcmil [16 to 150 mm2]. Lugs require 5/16" hex key tool for installation. Torque to 250 lb-in [28.2 N-m]. Lugs are mounted on threaded studs and may be removed if desired. Studs are 3/8" [9.525mm] diameter and nuts should be torqued to 192 lb-in [21.7 N-m].
- "Neutral Bus and Ground Bus are provided with 3/8"-16 threaded studs (9.525mm diameter).
- Tighten nuts to 25 lb-ft (300 lb-in) [33.9 N-m]"

WARNING: The ProDySC must be safety-grounded according to the National Electric Code. In addition, all local, state, and federal regulations applicable to the installation of electrical systems as well as accident prevention regulations must be strictly observed

Communications

Both dry contacts (relays) that indicate status and a Serial Communications Port (RS-232) are available for monitoring the ProDySC.

Dry Contacts

Three relay contacts indicate ProDySC status. The contacts are form A and close upon occurrence of the named event: (a) any SAG EVENT, when rms input voltage drops below 88.5% of rated value; (b) OUTPUT OK, when output voltage remains between 87% and 110%; and (c) a system ALARM event. The relay contact ratings are 24V at 1A.

For access, remove the small metal cover from the top of the ProDySC (See Figure 6).

- All wiring is to be Class 2, limited to 24 Volts, AC or DC.
- Acceptable wire gauges range from 24AWG to 12AWG (0.205-2.5mm2).
- Torque connections to 5.0 lb-in (0.6 N-m).
- For permanent installation of communications conductors, a standard conduit knockout is located on the cabinet top (See Figure 2).

Figure 6 - Access Cover Location



Serial Communications Port

The ProDySC serial port is a DE-9 female connector. The pin-out follows standard RS-232 protocol: pin 2 is RxD, pin 3 is TxD and pin 5 is common (return). All other pins are unused. Contacts are galvanically isolated from the system power and grounds.

- Protection: The RS-232 port is ESD-protected to 15kV.
- Protocol: 57.6k bps, 8 data bits, one stop bit, no parity, flow control off
- Data packets are SLIP encoded (with 2 byte length field).
- Data accessible through this port includes load voltages, load currents, status, and event and diagnostic logs.
- Consult Rockwell Automation technical support for specifications to the ProDySC SLIP protocol.

Figure 7 - Serial Communications Port



Applying Power

- Before applying power to the ProDySC, make certain there are no metal filings or any conductive debris in or on any components inside the ProDySC.
- Verify ProDySC voltage rating matches ac source voltage.
- Ensure that all input/output wiring including grounding has been completed, all covers are replaced, and that access doors are closed and locked.
- Place the ProDySC internal circuit breaker in the OFF position.
- Apply power from the upstream branch protection device. Power will not flow through to the load. The ProDySC touchscreen will become active.
- Place the ProDySC internal circuit breaker in the ON position.
- Ensure that the touchscreen displays "OK" in the upper left corner and that the nominal voltage, current, and frequency in the status display are correct.
- If a "Critical" or "Fatal" system event appears on the touch screen call for technical support.
- Verify that the output (load) voltage is present and within its nominal rating.

WARNING: The ProDySC is interlocked. Opening ProDySC doors while the system is in operation will trip the internal circuit breaker and result in loss of power to protected loads.

NOTICE: Cycling ProDySC input power in the sequence OFF--ON--OFF--ON within a one minute period will cause a “Limit Cycle Timeout” alarm. In such case sag correction will be inhibited for one minute, after which the alarm will automatically reset.

Notes:

Display Screen

Overview

The ProDySC® touch screen display is a window to voltage sags and ProDySC protection. The display provides system status, voltage sag notification and history, runtime statistics and system history in a simple and intuitive touch-based user interface.

When the system first starts, a welcome screen displaying the ProDySC product logo appears. This screen disappears after 5 seconds, when the “Home” screen appears.

Note: The touch screen is optimized for use with a plastic stylus or bare finger.

At installation time perform the following steps to configure your system:

Step 1: Press the "CONFIG" button at the bottom of the “HOME” screen (See Figure 8).

Figure 8 - Home Screen



Step 2: Begin calibration by pressing "CALIBRATE TOUCH SENSOR" (See Figure 9).

Figure 9 - System Configuration



Note: To recalibrate from any screen, hold anywhere on the screen for 10 seconds. You will see a small progress bar at the bottom of the screen. When the progress bar reaches 100 percent, the calibration screen will open.

Step 3: The "Touch Screen Calibration" screen will then appear (See Figure 10). Press and hold on the center of the touch target, release when the touch target begins to flash. Repeat with the next two touch targets.

Step 4: The screen uses the new calibration configuration. You can test the calibration before saving by pressing anywhere on the screen to ensure the touch target appears where you press. After testing, press the "SAVE" button. Press the "BACK" button to return to the "System Configuration" screen.

Figure 10 - Touch Screen Calibration



Figure 11 - Set System Date and Time

Step 5: Set date and time by pressing "SET SYSTEM CLOCK" in "System Configuration." Press “SAVE” when completed.



Home Screen

The "HOME" screen of the display provides a snapshot view of the status of the entire system (See Figure 12). You can return to this screen from any other screen by pressing the "HOME" button. After 5 minutes of inactivity (i.e. not pressing the screen), the touch screen will automatically return to the “HOME” screen. The “HOME” screen is divided into four main areas described inTable 2.

Figure 12 - Home Screen



Table 2 - Home Screen Description

Description	Function	
Status	Real-time system operation: available runtime, output line-to-neutral (L-N) or line-to-line (L-L) voltage (model dependent), load current, and frequency	
Last Voltage Sag	Rotating information about the last voltage sag: event start time, event duration, and sag depth	
Statistics	Summary view of ProDySC performance based on sags detected, plus a rotating display of last power-up date, elapsed time (since power up), and total up-time	
Main Menu	The menu buttons at the bottom of the screen navigate through: **VOLTAGE SAGS:** Displays the “Voltage Sag Log” screen **CONFIG:** Displays the “System Configuration” screen	**STATUS:** Displays the “System Status” screen **SYSTEM EVENTS:** Displays the “System Event Log” screen

System Status

The "System Status" screen displays the real-time overall system status. Reach this screen by pressing "STATUS" on the "HOME" screen or the “Status” area at the top of the “HOME” screen

Figure 13 - System Status Summary



Figure 14 - - System Status Waveforms



Table 3 - System Status Description

Description	Function
System Status	Overall system status including current operational status, availability to correct sags, and internal cabinet temperature
Phase Status	Voltage, current, frequency, and static switch temperature are displayed for all phases. The percentage displayed following the voltage and current is the percent of nominal value for the ProDySC. Nominal values are listed on the "View Model Information" screen.
Waveforms	A sample of a 4 cycle waveform that includes real-time line voltage, load voltage, or load current can be selected for display

Voltage Sag Events

A voltage sag is defined as the period when input RMS voltage drops to less than 88.5% of the rated DySC voltage. Details of each voltage sag and corresponding ProDySC protection are captured and saved to the voltage sag log.

Voltage Sag Log

The "Voltage Sag Log" screen (See Figure 15) displays a list of the last 61 voltage sags. Reach this screen by pressing "VOLTAGE SAGS" button on the "HOME" screen.

Figure 15 - Voltage Sag Log



Table 4 - Voltage Sag Log Description

Description	Function
#	Unique ID within the list (0-60) to identify the voltage sag
Time	Start time and date of the voltage sag
Check Mark	Denotes the ProDySC protected the voltage sag
RMS %	Worst-case RMS voltage (percent of nominal) across all phases
Duration	Duration of the voltage sag

Note: Use the up/down arrows to navigate through the list. Press the "SELECT" button to view additional details about the voltage sag

Voltage Sag Detail

Voltage Sag Detail" screen (See Figure 16) displays all information related to the selected event. Details for the most recent sag event can also be accessed by pressing anywhere in the Last Voltage Sag area of the HOME screen.

The worst-case RMS voltage recorded during the event is displayed in the upper window along with the corresponding voltage percentage and the event duration. Table 7 describes the remaining screen content.

Figure 16 - Voltage Sag Detail



Table 5 - Voltage Sag Detail Description

Description	Function
Sag Summary	**ID**: Unique ID within the list (0-60) to identify the voltage sag **Time:** Start time of the voltage sag **RMS:** Worst-case RMS voltage (L-N) and percent of rated voltage across all phases **Duration:** Duration of the voltage sag **Frequency:** Frequency of the line prior to the start of the voltage sag **Temperature:** Internal temperature of the PRODySC prior to the start of the voltage sag
Sag Magnitude	**Line Voltage:** Line RMS voltage and percent of rated (L-N). Voltages ≤ 80% of nominal are displayed in red. **Load Voltage**: Load RMS voltage and percent of nominal (L-N).
Correction Result	The "Correction Result" is displayed in a box in the upper-right-hand corner of the "Event Summary" section. The "Correction Result" conveys how the PRODySC performed correcting the voltage sag. The possible values are: **Protected**: The output RMS voltage on all phases is ≥ 85 percent of nominal and the PRODySC correction was active for the duration of the voltage sag (will be displayed in green). **Run Error**: An unexpected system event occurred during the sag (will be displayed in orange) **Run Inhibite**d: The PRODySC system was inhibited when the sag occurred (will be displayed in orange).

Note: The "Voltage Sag Detail" for the most recent event can also be accessed by pressing the "Last Voltage Sag" area of the "HOME" screen.

Voltage Sag RMS Voltage Charts

The line and load RMS voltage (L-N) of each phase is recorded for 8 cycles prior to the start of the voltage sag followed by the first 300 cycles of the voltage sag (See Figure 17). Reach this screen by pressing "CHARTS" on the "Voltage Sag Detail" screen as shown in Figure 16 on page 21.

Figure 17 - - RMS Voltage Charts



Line voltage is shown in red and load voltage is shown in green. By pressing the check boxes in the right column, you can toggle each data series Off and On as well as enable y-axis auto-scaling.

Note: 300 cycles = 5.0 seconds at 60 Hz or 6 seconds at 50 Hz.

Voltage Sag Notification

While the voltage sag is in-progress, a flashing red box in the upper left-hand corner will display "SAG-IN-PROGRESS." This box will appear on every screen until the voltage sag ends. See Figure 18.

Figure 18 - Voltage Sag Detected



System Events

The ProDySC tracks all operational events which are classified into five groups based on severity.

Table 6 - System Event Description

Description	Function
Informational	Purely informational. No action is required.
Auto-Resetting	The PRODySC will reset within 60 seconds. No user action is required.
User Attention	User action may be required to correct a problem. The PRODySC will reset 60 seconds after the error condition is corrected.
Manual-Reset	For system events that cause circuit breaker CBI to open a manual reset of the DySC system will be required.
Call Service	For events classified as Call Service, factory trained service support will be required. Contact Rockwell Automation technical support.

System Event Log

The "System Event Log" screen displays a list of the last 40 system events in chronological order (See Figure 19). Reach this screen by pressing "SYSTEM EVENTS" on the "HOME" screen.

Figure 19 - System Event Log



Table 7 - System Event Log Description

Description	Function
#	Unique ID (0-39) to identify the system event (unique within the list)
Time	Start time of the system event
Name	Short name of the system event.
Severity	Severity of the system event

Note: Use the up/down arrows to navigate through the list. Press the "SELECT" button to view additional detail about the system event.

System Event Detail

The "System Event Detail" screen is displayed when a specific system event is selected by pressing on the "SELECT" button on the "SYSTEM EVENT LOG" screen (See Figure 19 on page 23). It provides detailed information that was recorded during the event (See Figure 20).

Figure 20 - System Event Detail



Table 8 - System Event Detail

Description	Function
Time/Duration	**Time:** Date and start time of the system event **Duration:** The amount of time the event lasted.
Type	**Event ID:** Unique ID within the list (0-39) to identify the event. **Code:** Abbreviation of the event followed by a numeric event code in parentheses. (For a list of codes and abbreviations see Table 10 on page 30 **Severity:** Severity of the event **Description:** Name of the event see Table 10 on page 30
Component	**Location:** The location in the system where the event originated (i.e. Phase A, Phase B, Phase C, etc.). **Area:** The specific area within the location where the event originated (i.e. Inverter, etc.). **Reading:** a data value relevant to the System Event may be recorded in some cases, e.g., detail for an "Inverter Over-Current" alarm would include a reading of the causal high current value. The reading "N.A." is displayed if no appropriate data value exists.

System Event Notification

When the ProDySC system first detects an event condition, the "System Fault Detection" dialog box will be displayed (See Figure 21). Within the "System Fault Detection" box, the name, severity, and location of the event will be displayed.

Figure 21 - System Fault Detection



Pressing the "OK" button will open the "System Event Detail" screen. The event will appear in the event list after the event is over. The window can be closed by pressing the "CANCEL" button or waiting 15 seconds.

When the event condition clears, a new dialog box will be displayed. Press "OK" to view the complete event detail, or "CANCEL" to close the dialog box (See Figure 22).

Figure 22 - System Fault Detection - Cleared



If a "Call Service" severity event is detected, record the event details including: name, description, location, and reading. Contact product support immediately. If the event clears, the touch screen will automatically go back to normal operation.

System Configuration

Press the "CONFIG" button at the bottom of the “HOME” screen to enter the “System Configuration” screen (See Figure 23). The “SET SYSTEM CLOCK” and “CALIBRATE TOUCH SENSOR” functions are described at the start of this chapter.

Figure 23 - System Configuration



Model Information

Touch “VIEW MODEL INFORMATION” to go to the “Model Information” screen. (See Figure 24).

Figure 24 - Model Information



Table 9 - Model Information

Description	Function
Model Details	**Model Number:** System Model number **Serial Number:** System serial number **System Rating:** System voltage and current ratings
Unit Details	**Node:** The location index for the details listed to the right **Firm:** The firmware version for the location indexed. **Type:** Unique code specifying firmware part number for the location indexed. **Serial:** The serial number for the location indexed **Volts:** The rated voltage for the locations **Amps:** The rated current for the location indexed

Run System Tests

Press the "RUN SYSTEM TESTS" to enter the “System Tests” screen. Press “2 MINS” to run the system fans for 2 minutes (See Figure 25).

Figure 25 - System Tests



Diagnostics Mode

This is not a user function. It is numerical code protected for authorized service personnel.

Notes:

Maintenance

Preventative Maintenance

The ProDySC requires very little preventative maintenance. The ProDySC should be checked periodically for proper air flow and status indicator operation.

Monthly Checks

- Ensure the touch screen display is working and no active events are displayed.
- Update system time, if needed, Figure 11 on page 18.
- Use a soft cloth to clean the touch display. DO NOT USE harsh detergent, abrasive sponges, alcohol, ammonia, toluene, or acetone on the touch display.
- Ensure air intake and exhaust filters are not covered or obstructed.

3-6 Month Checks

- Check air filters and clean when necessary.
  - Air filters for the ProDySC will require periodic cleaning, with the frequency depending on the environment. Filters are located on the front side of the ProDySC, and can be accessed with the door closed. The ProDySC need not have power removed for this operation. Remove the grill covers by unscrewing the knurled nuts; the washable foam filter pads are behind the grill cover. Gently wash the foam filter pads as needed with a light non-abrasive soap and water mixture. Towel-dry; do not wring-out. Place the filter and grill cover back into their location and replace the screw caps by rotating clockwise until finger tight. Replace filter if damaged. Consult Rockwell Automation technical support for replacement filters. Replacement filters must be no more restrictive to air flow than the original equipment filters.
- Check fan for proper operation.
  - Tap on “CONFIG” on the touch screen display. Tap on “Run System Test”. This will bring up a “System Test” screen to test the fans. After tapping the “Fan Test” button, you should hear the fans run for two minutes.

Table 10 - System Event Table

Event Code	Code Name	Full Name	Severity	Area	Event Description	Event Resolution
1	POWER_ON	DySC Power On	Informational	Unit	Power re-applied to the DySC.	No action needed.
4	T_FAN_ST	Fan Test Start	Informational	Unit	Start acknowledgment of DySC fan test.	No action needed.
5	T_IN_ST_1	Inverter Test (.5 cycles) Start	Informational	Unit	Start acknowledgment of DySC 0.5 cycle inverter test.	No action needed.
6	T_IN_ST_2	Inverter Test (3 cycles) Start	Informational	Unit	Start acknowledgment of DySC 3 cycle inverter test.	No action needed.
7	T_IN_ST_3	Inverter Test (5.5 seconds) Start	Informational	Unit	Start acknowledgment of DySC 5.5 second inverter test.	No action needed.
9	EXTERNAL	External Inhibit	Auto-Resetting	Inverter	Controller is inhibited by another phase controller.	Review event details from other phase controllers.
11	RUN_TO	Inverter Run Timeout	Auto-Resetting	Inverter	DySC inverter had a total cumulative runtime of more than rated.	No action needed.
12	LIM_CYCLE	Inverter Limit Cycle Timeout	Auto-Resetting	Inverter	Power was re-applied more than once within a 58 second period.	No action needed.
13	STAT_OT	Static Switch Over-Temperature	User Attention	Static Switch	Static switch heatsink temperature was greater than maximum rating.	Verify ambient temperature is within DySC specification. Check for damaged fans. Check for dirty or obstructed air
14	OVERLOAD	Overload	User Attention	Unit	Inverter inhibited because load current exceeded maximum rating.	Reduce load. In parallel DySC systems, verify proper current sharing among slave cabinets.
15	DC_OV	DC Bus Over-Voltage	User Attention	Inverter	Positive or negative half of DC bus voltage exceeded maximum rating.	Verify line voltage is within ratings. Verify proper DySC application. Call service.
16	CNTRL_UV	Controller Power Under-Voltage	User Attention	Inverter	DySC control power supply is out of tolerance.	Verify DySC is online and line voltage is within ratings. Call service.
17	OUTPUT_UV	Output Under-Voltage	User Attention	Inverter	DySC output voltage was less than 80% of nominal during sag correction. Sag condition likely outside of DySC specification.	Verify line voltage is within ratings. Verify proper DySC application.
18	INV_OC	Inverter Over-Current	User Attention	Inverter	Inverter current exceeded maximum rating during sag correction.	Verify load current is within ratings. Verify mechanical bypass switch is open. Verify proper DySC application.
19	DC_UV	DC Bus Under-Voltage	User Attention	Inverter	DC bus voltage below operational range.	Verify line voltage is within ratings. Call service.
20	OUTPUT_OV	Output Over-Voltage	Call Service	Inverter	DySC output voltage was greater than 115% of nominal during sag correction.	Call service.
25	SYNC_ERR	Line Synchronization Error	Call Service	Inverter	Inverter not synchronized to line when sag detected.	Call service.
31	CONFIG	Configuration Alert	Call Service	Inverter	Controller configuration has changed.	Call service.
32	CNTRL_MEM	Controller Memory Busy	Auto-Resetting	Inverter	Controller is loading new data into Flash memory.	No action needed.
33	UNBALANCE	Start-Up Test: DC Bus Unbalance	Call Service	Inverter	Positive and negative halves of the DC bus did not charge equally during power up.	Call service.
34	AC_V_CHK	Start-Up Test: AC Voltage Check	Call Service	Inverter	Output voltage was detected out of tolerance during the start-up test.	Call service.
35	ROLL_CALL	Start-Up Test: Controller Roll Call Timeout	Call Service	Unit	Controller communication problem detected during start-up test.	Call service.
36	COM_VER	Start-Up Test: Communication Compatibility Mismatch	Call Service	Unit	Firmware communication compatibility problem detected during start-up test.	Call service.
37	CNFG_TO	Start-Up Test: Controller Configuration Timeout	Call Service	Unit	Controller communication problem detected during start-up test.	Call service.
38	CNFG_ERR	Start-Up Test: Controller Configuration Mismatch	Call Service	Unit	Controller firmware configuration problem detected during start-up test.	Call service.
39	FIRM_TO	Start-Up Test: Controller Firmware Check Timeout	Call Service	Unit	Controller communication problem detected during start-up test.	Call service.
40	FIRM_DIFF	Start-Up Test: Controller Firmware Revision Mismatch	Call Service	Unit	Controller firmware revision mismatch detected during start-up test.	Call service.
41	SRL_TO	Start-Up Test: Controller Serial Number Check Timeout	Call Service	Unit	Controller communication problem detected during start-up test.	Call service.

Event Code	Code Name	Full Name	Severity	Area	Event Description	Event Resolution
42	SRL_DIFF	Start-Up Test: Serial Number Mismatch	Informational	Unit	Controller serial number mismatch detected during start-up test.	No action needed.
44	T_INV_TO	Inverter Test Timeout	Call Service	Unit	Phase control board failed to respond to Comm board's Inverter test.	Call service.
46	DOOR_OPEN	DySC Cabinet Door Open	Manual Reset	Unit	DySC door was opened. Mechanical bypass commanded.	Close door. Manually reset DySC.
47	CRIT_OT	Critical Over-Temperature	Manual Reset	Unit	Internal DySC temperature exceeded maximum rating. Mechanical bypass commanded.	Verify ambient temperature is within DySC specification. Check for damaged fans. Check for dirty or obstructed air filters. Manually reset DySC.
48	FUSE_OPEN	Fuse Open	Call Service	Unit	One of the DySC fuses was detected open. Mechanical bypass commanded.	Call service.
49	OPEN_SCR_A	Open SCR Phase A	Call Service	Static Switch	The SCR on the phase A module was detected open.	Call service.
50	OPEN_SCR_B	Open SCR Phase B	Call Service	Static Switch	The SCR on the phase B module was detected open.	Call service.
51	OPEN_SCR_C	Open SCR Phase C	Call Service	Static Switch	The SCR on the phase C module was detected open.	Call service.
53	DYN_BRAKE	Dynamic Brake Error	Call Service	Unit	A problem was detected with the DySC dynamic brake controller.	Call service.
58	PLC_ERR	Programmable Logic Controller Error	Call Service	PLC	PLC error detected.	Call service.
59	PLC_ST_MM	Programmable Logic Controller State Mismatch	Call Service	Unit	PLC feedback error detected.	Call service.

Fuse Replacement

Fast-acting fuses are included to protect the ProDySC in the event of a load short circuit. If the screen is dark when power is applied, it may indicate a blown fuse. Check the fuse(s) for continuity.

WARNING: Turn the power to the ProDySC off by placing the Bypass Switch into "BYPASS" or opening the branch circuit breaker before replacing the fuse. Failure to comply with this warning can result in injury or death.

The ProDySC has high voltage remaining up to 5 minutes after disconnection from the AC line. Touching exposed or disconnected terminals, cables or parts of the ProDySC can lead to serious injuries or even death. Wait for a minimum of 5 minutes before performing any service or testing on the DySC after power is removed.

Keep the cabinet doors closed to ensure proper cooling airflow and to protect personnel from dangerous voltages inside the ProDySC.

IMPORTANT A qualified electrician must replace the fuse. Open the front cabinet door(s) to access the fuse holders and fuses.

To maintain protection of the ProDySC, be sure to replace the fuse with the same type and rating. These fuses are available from the factory. Provide the factory with the ProDySC model number located on the outside of the enclosure.

Fuse Rating Charts

Replace fuse with the same type or equivalent cross-referenced rating. You may order these fuses through Rockwell Automation or the manufacturer listed.

Table 11 - Pro DySC Fuse Ratings

Fuse Reference	Fuse Location	Fuse Rating	Manufacturer Part Number
F1, F2, F3	Main Cabinet: Main Power Input	600A/500V	Mersen A50QS600-4IL
F4, F5, F6	Main Cabinet: Cross-Coupling Transformer	100A/600V	Mersen AJT100
F7, F8, F9 (3 wire models only)	Main Cabinet: Neutral Forming Transformer	4A/600V	Mersen TRS4R
F10, F11 (200-220V models)	Main Cabinet: Input Control Transformer	2A/600V	Mersen TRS2R
F10, F11 (380-480V models)	Main Cabinet: Input Control Transformer	1A/600V	Mersen TRS1R
F12, F13	Main Cabinet: Cross Coupler Auxiliary	2A/600V	Mersen ATQR2
F14, F15 (200-220V models)	Main Cabinet: Output Control Transformer	8A/600V	Mersen TRS8R
F14, F15 (380-480V models)	Main Cabinet: Output Control Transformer	4A/600V	Mersen TRS4R
F16, F17, F18, F20	Main Cabinet: TVSS Input	40KA surge / 600V	Mersen VSP40-2
F19	Main Cabinet: Input Control Transformer	4A/600V	Bussmann FNQ-R-4
F1, F2	Power Module (x3): Voltage Feedback	2A/600V	Mersen ATQR2
F3	Power Module (x3):	--	Not Field Replaceable
F4, F5, F6, F7	Power Module (x3): Dynamic Brake	20A/600V	Mersen ATM20

Transient Voltage Surge Suppressor (TVSS)

The ProDySC includes an internal TVSS device (or SPD), protecting the output (load). Indicator lights on the TVSS show if surge protection is active. Power to the TVSS module may be removed by opening the block of fuses F16-F17-F18-F20. F20 is present only in 4-wire models.

Circuit Breaker CBI, Safety Interlocks and Stored Energy

If the cabinet doors are opened while the ProDySC is operating the circuit breaker CBI will be automatically opened and load power will be interrupted. Doors should be kept locked to avoid this situation. CBI is rated 250A, 3-pole, with thermal-magnetic trip and automatic shunt trip capability.

The ProDySC includes a fast-discharge circuit to quickly dissipate stored energy when the internal circuit breaker CBI is opened. CBI may be operated automatically by the door interlock switches or other protection devices. CBI can also be operated manually. The recommended procedure for performing any service inside the ProDySC begins with opening CBI before removing upstream power.

If the upstream power is interrupted before CBI is opened the fast-discharge circuit will not be triggered. In that case wait at least 30 minutes before opening the ProDySC doors to avoid exposure to charged capacitors. High voltage

Specifications and Dimensions

Table 12 - Technical Specifications 200 A ProDySC

Electrical Input/Output (Normal Mode—Static Switch)	
Connection Configuration	Series-connected with load. Under normal line condition, the static switch passes utility voltage directly to the load
Standard Input Voltages	3-phase: 208, 380, 400, 415, 480V[1]
Voltage Range	± 10%
Current Overload (Static Switch)	150% @ 30Sec., 400% @ 5 Sec., 600% @ 0.5 Sec.
Frequency	50/60 Hz Auto Sensing
Frequency Range	48 -62 Hz
TVSS	Output SPD, 25kA/mode. Protects L-L & L-G on all models; L-N & N-G (4-wire models)
Efficiency	> 99% @ 480V
Electrical Output (Sag Correction Mode - Inverter)	
Output Voltage	Pre-sag rms voltage
Voltage Regulation	± 5% typical, +5 % / -13% of nominal max
ProDySC Output Current	200 A_{RMS}[2] Not rated for DC loads; max. allowable 2% DC loading
Crest Factor (at nameplate rms load)	1.45
Voltage Waveform	Sine wave
Voltage Sag Correction Times	
Single Event	
3 phase 87% to 50% Voltage Remaining	5 seconds
All three phases to zero voltage remaining	3 cycles, based on nameplate ratings with a power factor of 0.7, and frequency of 60Hz
Multiple Event	
Max Sag Correction Time	5 seconds cumulative usage
Sequential Sag Recovery	0 seconds (assuming cumulative run-time available)
Full Recovery Time	Max 5 minutes
Mechanical	
Enclosure Ratings	NEMA 1 (IP20)
Cable Entry	Top or Bottom
Cooling	Filtered Forced Air
Access	Front for servicing and connections
Audible Noise	less than 60 dBA at 1m
Weight	1470 lb (667 kg)
Environmental	
Ambient Temperature	0 to 40°C
Storage Temperature	-40°C to 75°C
Relative Humidity	0 to 95% non-condensing
Altitude	Rated current available to 1000m (3300ft). De-rate output current 10% per 1000m, from 1000m to 3000m (9900ft).
Safety and Compliance	
Agency Approvals	cULus Listed (UL 1012)
Standards Compliance	Exceeds SEMI F47 Standard; IEEE Std C62.41.1 and UL 1449 3rd Ed. compliant

1. ProDySC has not been evaluated for use in Corner Grounded or Ungrounded Delta Power Systems in systems rated over 240V.
2. When using ProDySC with motor drive loads, either insert 3% to 5% line reactance at ProDySC output or limit motor drive loads to 60% of ProDySC rating

Table 13 - Heat Dissipation

Rating (V)	Heat Loss (W)	Heat Loss (Btu/h)	Efficiency (%)
208V	1035	3534	98.6%
480V	1325	4524	99.2%

Approximate Dimensions

Dimensions are shown in inches (millimeters). Dimensions are not intended to be used for manufacturing purposes.

Figure 26 - 200 A ProDySC Dimensions



Rockwell Automation Support

Rockwell Automation provides technical information on the Web to assist you in using its products. At http://www.rockwellautomation.com/support, you can find technical manuals, technical and application notes, sample code and links to software service packs, and a MySupport feature that you can customize to make the best use of these tools. You can also visit our Knowledgebase at http://www.rockwellautomation.com/knowledgebase for FAQs, technical information, support chat and forums, software updates, and to sign up for product notification updates.

For an additional level of technical phone support for installation, configuration, and troubleshooting, we offer TechConnect^{SM} support programs. For more information, contact your local distributor or Rockwell Automation representative, or visit http://www.rockwellautomation.com/support/.

Installation Assistance

If you experience a problem within the first 24 hours of installation, review the information that is contained in this manual. You can contact Customer Support for initial help in getting your product up and running.

United States or Canada	1.440.646.3434
Outside United States or Canada	Use the Worldwide Locator at http://www.rockwellautomation.com/rockwellautomation/support/overview.page, or contact your local Rockwell Automation representative.

New Product Satisfaction Return

Rockwell Automation tests all of its products to help ensure that they are fully operational when shipped from the manufacturing facility. However, if your product is not functioning and needs to be returned, follow these procedures.

United States	Contact your distributor. You must provide a Customer Support case number (call the phone number above to obtain one) to your distributor to complete the return process.
Outside United States	Please contact your local Rockwell Automation representative for the return procedure.

Documentation Feedback

Your comments will help us serve your documentation needs better. If you have any suggestions on how to improve this document, complete this form, publication RA-DU002, available at http://www.rockwellautomation.com/literature/.

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444
Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640
Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication 1608P-UM003A-EN-P - September 2013
Copyright © 2013 Rockwell Automation, Inc. All rights reserved. Printed in the U.S.A